



LAMP® PUSH KNOB LATCH PKL-07, PKL-08 INSTALLATION MANUAL

Thank you for selecting our product. Before starting installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

DIMENSIONS




DOOR PROCESS DIMENSIONS




INSTALLATION

1 Mounting Parts



2 Operation Check



Check if latch works properly while pushing the knob (once to lock, once again to unlock).

! Be sure to push the knob at closed position. Latch may be damaged if you close the door after pushing the knob.


3 Adjusting counter plate

Adjust the position so that the latch operation is smooth without backlash.



4 Fastening counter plate

With the round head wood screw fasten the plate through the round hole.



SUGATSUNE KOGYO CO., LTD.
Tokyo, JAPAN

Phone: +81 3 3866 2260
E-mail: export@sugatsune.co.jp

SUGATSUNE KOGYO (UK) LIMITED
Reading, UK

Phone: +44 1189 272 955
E-mail: sales@sugatsune.co.uk

SUGATSUNE EUROPE GmbH
Düsseldorf, GERMANY

Phone: +49 211 53812 900
E-mail: sales@sugatsune.eu

SUGATSUNE AMERICA, INC.
California, USA

Phone: +1 310 329 6373
E-mail: sales@sugatsune.com

Chicago, USA

Phone: +1 630 317 7072
E-mail: sales@sugatsune.com

SUGATSUNE CANADA, INC.
Montreal, CANADA

Phone: +1 514 312 5267
E-mail: support@sugatsune.ca

SUGATSUNE SHANGHAI CO., LTD.
Shanghai, CHINA

Phone: +86 21 3632 1858
E-mail: lamp@sugatsune.com.cn

Guangzhou, CHINA

Phone: +86 20 6639 3554
E-mail: lamp@sugatsune.com.cn

SUGATSUNE KOREA CO., LTD.
Incheon, KOREA

Phone: +82 32 220 0603
E-mail: sales@sugatsune-korea.co.kr

SUGATSUNE KOGYO INDIA PRIVATE LIMITED
Mumbai, INDIA

Phone: +91 9867299597
E-mail: sales@sugatsune.in

Delhi, INDIA

Phone: +91 9867299597
+91 11 45093636
E-mail: sales@sugatsune.in